

5M050006

OPTIONAL HIGH WIND MOUNTING

Part No. SK34

ROOF • RACK • FENCE

TOOLS:

- Silicone Sealant, (GE II or equivalent) if on roof.
- Phillips Head Screwdriver
- Hand Drill with 1/8" drill bit

1. Complete the roof/rack mounting procedures as indicated in kit SK43 (for aboveground pool SunHeaters) or SK21 (for inground pool SunHeaters).
2. Position brackets approximately 6" away from headers. Drill 1/8" pilot holes for all brackets. Lag screws should be long enough to reach the sub-roof under the shingles. Inject a generous amount of silicone sealant into the holes and onto the surrounding roof surface. Cover screw head with silicone after screw is tightened down.
3. Loop 2' strap provided around header between collector area and end cap or collector connector hose. Draw both ends of strap through slot in bracket. Tie knot in strap so knotted end of strap cannot be pulled through bracket slot. Leave some "play" in loop so collector can expand and contract up to one inch.

