Aboveground Cover Kit Instructions VII. ATTACHING THE SOLAR COVER TO REEL

(Refer to Step #1 and #2)

- Your cover should be on the pool and the cover should be trimmed to inside of pool's top rail.
- With a magic marker, place a mark at each edge of the cover directly below the tube.
- Remove cover from pool and lay out on flat ground.
- With a magic marker, draw a straight line between the two marks on the cover.
- 5. Roll cover up until you reach the drawn line.
- Measure in 8 inches from each side of cover, and place a cross mark on the line.
- From this position, take the measurement used between the first tube marks. (Step#1) and space cross marks down the line to the second 8 inch measurement.

VIII. ATTACHING THE CORD PLATES

(Refer to Step #3)

- Take one set (male and female) of the cord plates and place the female plate over the first cross, 8 inches from the cover edge. Make sure the center hole is placed above the cross. (Refer to Step #1).
- With a sharp instrument, Punch 3 holes through the plate and cover. (Make certain the HOLES are clean of excess cover material.)
- Place a male plate under the cover directly beneath the female plate.
- Carefully insert the 2 male prongs through the cover and into female plate, then snap together. If the plates do not snap into position with normal force, remove all excess cover material. Repeat procedure until all plates have been installed.

IX. ATTACHING THE WHITE CORD

(Refer to Step #4)

- Place 2 foot white cord through the top of the female plate in center hole, and push through cover and male plate until enough cord remains to tie a knot below the male plate.
- Tie a secure knot, large enough so that it cannot go through the center hole.
- Install cover on the pool, attempting to keep one side in the rolled up position.
- ENTER POOL. Attach top of the white cord through tube eye screws. MAKE CERTAIN ALL CORDS HAVE THE SAME TENSION. Then tie cord to tube eye screw, being careful to keep equal tension.







