


Solar Heater Bypass Kit


Connecting Multiple Units

Instructions

1. Turn off filter / pump and block off water from the pool at filter / pump and pool return connections.
2. Disconnect pool return hose from the filter / pump.
3. To Install bypass kit:
 - a. Install threaded connectors into bypass valve with Teflon tape.
 - b. Install pressure gauge into "T" connector.
 - c. Connect solar heaters as shown in figure below using included hoses and hose clamps.
4. Unblock water and turn on filter / pump.
5. Adjust bypass valve as needed to achieve desired flow.



Bypass Valve Control:



Bypass Kit includes:

- 1 - Bypass Valve
- 1 - "T" Connector
- 1 - Pressure Gauge
- 3 - Dia 32mm (1¼in) / 38mm (1½in) Threaded Connectors
- 1 - Dia 38mm (1.5in) x 1.8m (72in) Flex Hose
- 6 - Stainless Steel Hose Clamps
- 1 - Teflon Tape