





INSTRUCTION SHEET



When you install the straps to the collar cover they must be in equal distance one from the others. The straps length must be adjust in function of the shape of the pool.

You must drill holes in aluminium tubing to fix straps which are already attached to collar cover.

INS-1120